

SFT02-191 SFT02-192 SFT02-198 SFT02-199 SFT02-200 SFT02-201 SFT02-202 SFT02-203 SFT02-204 SFT02-205



点火锁芯	后轮挡泥板 (高顶)	后挡泥板支架 右	后挡泥板支架 左	暖风箱外壳	暖风箱外壳	暖风箱滤网外 盖	仪表盘	消音器踏板	风扇叶支架
STARTER CYLINDER	REAR MUDGUARD (HIGH TYPE)	BRACKET	BRACKET	WARM TANK SHEEL	WARM TANK SHEEL	COVER	GUIDANCE SECTION CASE	MUFFLER UPPER STEP	FAN PROTECTO R HOLDER ALUMINUM
1346235 581025	1357601	1479924 1362711	1374500	1731388	1451864	1480457	1109992	1545149 1421621	1484890 1518458
SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)

SFT02-206 SFT02-207 SFT02-208 SFT02-209 SFT02-210 SFT02-211 SFT02-212 SFT02-213 SFT02-214 SFT02-215



后挡泥板支架	电瓶盖	驾驶室横梁支 架 (高顶) 右	驾驶室横梁支 架 (高顶) 左	面板锁 (高/ 低顶)	邮箱固定支架 (标准型)	邮箱固定支架 (加宽型)	消音器外罩支	空滤进气软管	空滤进气管
REAR MUDGUARD BRACKET	BATTERY COVER	TURRET(R) RH	TURRET(R)L H	CAB TILT LOCK REAR(R&P)	FUEL TANK HOLDER GENERAL	FUEL TANK HOLDER WIDE	MUFFLE BACK	AIR INLET	AIR INLET
1378187	1362693	1728320 1343094	1343093 1728319	1383496	1528608 1528909	1528906 1528907	1382024	1496691	1777816
SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)

SFT02-216 SFT02-217 SFT02-218 SFT02-219 SFT02-220 SFT02-221 SFT02-222 SFT02-223



空滤进气管 支架	空滤进气管 卡扣	空滤进气管 固定架	挡泥皮	挡泥皮	挡泥皮	挡泥皮	挡泥皮
AIR INLET BACKET	AIR INLET clip	AIR INLET clip	MUDFLAP L=170	MUDFLAP L=240	MUDFLAP L=310	MUDFLAP L=380	MUDFLAP L=450
1501291	1751398	1767631	1361760	1361762	1361764	1371766	1362002
SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)	SFT114 (R&P)

SFT03-096 SFT03-097 SFT03-098 SFT03-099 SFT03-100 SFT03-101 SFT03-102



面板后扭支架	外饰板 右	外饰板 左	遮阳罩前镜子	遮阳罩前镜子	车门 右	车门 左
FRONT PANEL FRAME	GARNISH RH	GARNISH LH	FRONT UNDER MIRROR W/GLASS (LOW/NORMA	FRONT UNDER MIRROR W/GLASS (TOP LINE)	DOOR RH	DOOR LH
1904814 1858803	1529886	1732322 1529885	1484076AR M 1484078	14847076 ARM 1484079	1476533 1739742	1476532 1739739
SFT420 P			SFT420 R&P	SFT420 R&P	SFT420 P	SFT420 P

SFT03-103 SFT03-104 SFT03-105 SFT03-106 SFT03-107 SFT03-108



车门 右	车门 左	面板锁	面板锁	铰链 右	铰链 左
DOOR RH	DOOR LH	CAB LOCK (R&P CABIN)	CAB LOCK (R&P CABIN)	HINGE RH	HINGE LH
1476535 1739743	1476534 1739740	1515436	1519439	1742265	1742264
SFT420 R	SFT420 R				

SFT04-059 SFT04-060 SFT04-061 SFT04-062 SFT04-063 SFT04-064 SFT04-065



铰链 右	铰链 左	铰链 右	铰链 左	下护罩支架 右	下护罩支架 左	保险杠
HINGE RH	HINGE LH	HINGE RH	HINGE LH	PROTECTO R BRACKET RH	PROTECTO R BRACKET LH	BUMPER
1852103	1852102	1889298	1889297	1889300	1889299	1787347

SFT04-066 SFT04-067 SFT04-068 SFT04-069 SFT04-070 SFT04-071 SFT04-072 SFT04-073 SFT04-074



立柱盖 右	立柱盖 左	保险杠 中	保险杠弯角 右	保险杠弯角 左	保险杠饰盖	LED灯	边灯	LED灯
PILLAR COVER RH	PILLAR COVER LH	CENTRAL BUMPER	BUMPER CORNER RH	BUMPER CORNER LH	BUMPER CENTER COVER	LED LAMP	SIDE LAMP	LED LAMP
1459364	1459363	1858428	1853839 1353843	1853838 1853842	1771116	1737413	1304787 1315121	1471599 1443884

SFT04-075 SFT04-076 SFT04-077 SFT04-078 SFT04-079 SFT04-080 SFT04-081 SFT04-082 SFT04-083



LED灯	边灯	消音器外罩	横梁支架 右	横梁支架 左	大灯外框 右	大灯外框 左	下护罩卡扣	空气滤清器外 壳上盖
SFT/VO LED LAMP	SIDE LAMP	MUFFLE COVER STEEL	BRACKET RH	BRACKET LH	HEAD LAMP CASE RH	HEAD LAMP CASE LH	GRILLE CLIPS	AIR FILTER COVER
1391144	1304788 1365972	1773834	1426196	1426195	1853355	1853354 1932223	1751398	1829713 1829712

SFT04-084 SFT04-085 SFT04-086 SFT04-087 SFT04-088 SFT04-089 SFT04-090 SFT04-091 SFT04-092



空气滤清器外 壳上盖	集风圈	集风圈	面板弯角 右	面板弯角 左	面板弯角风翼 板 右	面板弯角风翼 板 左	面板后组支架	面板后铰链 右
AIR FILTER COVER	FAN RING	FAN RING	PANEL CORNEL RH	PANEL CORNEL LH	PANEL CORNEL GARNISH RH	PANEL CORNEL GARNISH LH	FRONT PANEL FFRAME	HINGE RH
1869997	1788048 1724148(760 MM)	1530783(690 MM)	1751406	1751405	1856476	1856477	1917216 1859174	1451528

SFT04-093 SFT04-094 SFT04-095 SFT04-096 SFT04-097 SFT04-098 SFT04-099 SFT04-100 SFT04-101



面板后铰链 左	面板铰链盖 右	面板铰链盖 左	支架 右	支架 左	固定夹	边肚板 右	边肚板 左	进气管 (低 顶)
HINGE LH	PANEL HINGE COVER RH	PANEL HINGE COVER LH	FAN PROTECT RING HOLDER	FAN PROTECT RING HOLDER	MESH CLAMP	PEAR PILLAR RH	PEAR PILLAR LH	AIR INLET (LOW TYPE)
1451527	1479759	1479758	1772441	1772442	1805399	1892707	1892706	1888966

SFT04-102 SFT04-103 SFT04-104 SFT04-105 SFT04-106 SFT04-107 SFT04-108 SFT04-109 SFT04-110 SFT04-111



进气管 (高 顶)	进气管 (中 顶)	保险杠支架 右	保险杠支架 左	限位器	消音器支架	驾驶室横梁支 架 右	驾驶室横梁支 架 左	面板上通风网 饰盖 (低顶) 右	面板上通风网 饰盖 (低顶) 左
AIR INLET (HIGH TYPE)	AIR INLET (MIDDLE TYPE)	BRACKET RH	BRACKET LH	DOOR STOP	MUFFER BRACKET	TURRET RH	TURRET LH	PANEL UPPER GARNISH (CP)RH	PANEL UPPER GARNISH (CP)LH
1888968	1888967	1923153	1923152	1930649	1497657	1762856	1762855	1930823	1930822

SFT04-112 SFT04-113 SFT04-114 SFT04-115 SFT04-116



保险杠侧铁 板	保险杠侧铁 板	前轮挡泥皮	前轮挡泥皮	前轮挡泥板 支架
BUMPER CORNER RH	BUMPER CORNER LH	MUDFLAP	MUDFLAP	MUDFLAP BACKET
1431583	1431582	1762296	1762295	1522190